

The connecting procedure and what you will need will differ in the following cases:

- 1) When coiled handset cable can be removed from the handset and
- 2) When coiled handset cable cannot be removed from the handset

■ What You Will Need

- 1) When coiled handset cable can be removed from the handset



You need R-Talk 800EX and the business phone you have. The type of the phone line does not matter. →Go to How to Connect ①

- 2) When coiled handset cable cannot be removed from the handset



You need R-Talk 800EX, the included handset cable, and business phone you have. The type of the phone line does not matter. →Go to How to Connect ②

*The image shows when R-Talk 800EX is powered by battery (not included).
You can use the dedicated power adapter included in R-Talk 800EX if preferred.

The procedure for using the phone when the handset coiled cable can be removed



1 Remove coiled cable from the handset



2 Insert the coiled cable into the handset cable outlet of the R-Talk 800EX



3 Preparation is completed once the cable is properly connected



4 Take the handset off the hook and call the other party



5 Start the conference when you hear the voice on the other end. Talk through R-Talk



6 When the conference is over, hang up by putting the handset back in place

The procedure for the phone when the handset coiled cable cannot be detached



1 Remove the coiled cable from the outlet of the body of the phone. Keep the handset in place



2 Insert the handset cable (included) into the outlet of the body where coiled cable was removed in [1]



3 Insert the other end of the handset cable into the handset outlet of the R-Talk



4 Preparation is completed once the cable is properly connected



5 Take the handset off the hook and call the other party



6 Start the conference when you hear the voice on the other end. (Hang up by putting the handset back when the conference has ended.)

! Common Mistakes

Examples of wrong setup when using landline phone

Please check the connection one more time before contacting us

✗ Example of Wrong Setup

Handset is connected to R-Talk



○ Correct Setup

Body of the phone and R-Talk is connected



*The image shows when R-Talk 800EX is powered by battery (not included).
You can use the dedicated power adapter included in R-Talk 800EX if preferred.